









**IC1 D/A DATA OUT**

FREQUENCY	PM	2	3	4	5	6	7	8	9	10	11
0.00 KHz	L	L	L	L	L	L	L	L	L	L	L
0.01	L	L	L	L	L	L	L	L	L	L	L
0.02	L	L	L	L	L	L	L	L	L	L	L
0.03	L	L	L	L	L	L	L	L	L	L	L
0.04	L	L	L	L	L	L	L	L	L	L	L
0.05	L	L	L	L	L	L	L	L	L	L	L
0.06	L	L	L	L	L	L	L	L	L	L	L
0.07	L	L	L	L	L	L	L	L	L	L	L
0.08	L	L	L	L	L	L	L	L	L	L	L
0.09	L	L	L	L	L	L	L	L	L	L	L
0.10	L	L	L	L	L	L	L	L	L	L	L
0.11	L	L	L	L	L	L	L	L	L	L	L
0.12	L	L	L	L	L	L	L	L	L	L	L
0.13	L	L	L	L	L	L	L	L	L	L	L
0.95	L	L	L	L	L	L	L	L	L	L	L
0.96	L	L	L	L	L	L	L	L	L	L	L
0.97	L	L	L	L	L	L	L	L	L	L	L
0.98	L	L	L	L	L	L	L	L	L	L	L
0.99	L	L	L	L	L	L	L	L	L	L	L
1.00	L	L	L	L	L	L	L	L	L	L	L
0.0 KHz	L	L	L	L	L	L	L	L	L	L	L
0.1	L	L	L	L	L	L	L	L	L	L	L
0.2	L	L	L	L	L	L	L	L	L	L	L
0.3	L	L	L	L	L	L	L	L	L	L	L
0.4	L	L	L	L	L	L	L	L	L	L	L
0.5	L	L	L	L	L	L	L	L	L	L	L
0.6	L	L	L	L	L	L	L	L	L	L	L
0.7	L	L	L	L	L	L	L	L	L	L	L
0.8	L	L	L	L	L	L	L	L	L	L	L
0.9	L	L	L	L	L	L	L	L	L	L	L
1.0	L	L	L	L	L	L	L	L	L	L	L

**VFO MEMORY**

IC1-PM	33	34	35	36
VFO	A	L	L	L
MEMORY	OFF	L	L	L
NR	ON	L	L	L
SPT	OFF	L	L	L
WRITE	ON	L	L	L

**IC1-16 (E2) TRIGGER**

JM10	33	34	35	36
L	L	L	L	L
H	L	L	L	L

**VFO PITCH**

IC1-PM	33	34	35	36
VFO	100	L	L	L
POWER	OFF	L	L	L
ON	L	L	L	L

**IC1-15 (E3) TRIGGER**

JM10	33	34	35	36
L	L	L	L	L
H	L	L	L	L

**MODE SW**

BAND	MODE	J4	J4	J4	IC7	IC7	IC7	IC7
3.5 MHz	CW	L	L	L	L	L	L	L
-7 MHz	USB	H	H	H	H	H	H	H
10 MHz	CW	L	L	L	L	L	L	L
-20 MHz	USB	H	H	H	H	H	H	H

**BAND SW**

BAND	IC6	IC6	IC6	IC6
3.5 MHz	L	L	L	L
7	H	H	H	H
10	L	L	L	L
18	H	H	H	H
21	L	L	L	L
24.3	H	H	H	H
28	L	L	L	L
28.3	H	H	H	H
29.3	L	L	L	L
MC	L	L	L	L

**IC1-12 (E0) TRIGGER**

JM10	33	34	35	36
L	L	L	L	L
H	L	L	L	L